Workplace Health and Safety Bulletin WORK SAFE

Safe Work Permits

Introduction

Certain safeguards that normally protect the worker may have to be removed when repair or maintenance work is performed. When this occurs, the hazards involved need to be identified and a safe work system developed to eliminate or control these hazards

A safe work permit is document that identifies the work to be done, the hazard(s) involved, and the precautions to be taken. It ensures that all hazards and precautions have been considered before work begins. Safe work permits should always be used when work is performed by an outside agency or employer.



What is a safe work permit?

A safe work permit is a written record that authorizes specific work, at a specific work location, for a specific time period. Permits are used for controlling and co-ordinating work to establish and maintain safe working conditions. They ensure that all foreseeable hazards have been considered and that the appropriate precautions are defined and carried out in the correct sequence.

The permit is an agreement between the issuer and the receiver that documents the conditions, preparations, precautions, and limitations that need to be clearly understood before work begins.

Government of Alberta
Employment and Immigration



The permit records the steps to be taken to prepare the equipment, building, or area for the work, and the safety precautions, safety equipment, or specific procedures that must be followed to enable the worker(s) to safety complete the work.

The safe work permit helps to identify and control hazards, but does not, by itself, make the job safe.

Who benefits from a work permit program?

- Any industry that has a significant risk because of particular hazards.
- Any prime contractor who lets out or sub-contracts work to others to do maintenance or other hazardous work.
- Organizations that have individual employees working in isolated areas and performing non-routine work.

Why use a work permit?

All work exposes the worker to some degree of hazard. This degree of hazard determines the type of safeguards required to protect the worker. Most routine work has defined safe work practices or procedures. In the absence of such procedures, safe work permits should be used.

Workers engaged in maintenance work may be at risk if the machinery they are working on is started unexpectedly. Such machinery and equipment needs to be isolated by blanking, blinding, or a power lockout system. These procedures can be clearly identified by a work permit system.

Certain types or conditions of work, such as confined space entry, flammable or explosive situations, exposure to harmful substances or high voltage electrical equipment, and the transfer of hazardous work from one work shift to the next are examples of where safe work practices or the use of work permits is essential.

Alberta's Occupational Health and Safety (OHS) Act and OHS Regulation require employers to provide workers with a safe place of work and to identify known safety hazards. This can be partly achieved through the use of a safe work permit system. Verbal instructions can be misinterpreted or forgotten, whereas a great deal of control is achieved through the use of safe work practices or safe work permits.



Types of safe work permits

The type of safe work permit required is determined by the nature of the work to be performed and the hazards that must be controlled or eliminated. The range of activities and locations makes it impossible for a single type of permit to be suitable for all situations. The following types are most commonly used and examples are provided at the end of this Safety Bulletin.

Hot Work Permit

Hot work permits are used when heat or sparks are generated by work such as welding, burning, cutting, riveting, grinding, drilling, and where work involves the use of pneumatic hammers and chippers, non-explosion proof electrical equipment (lights, tools, and heaters), and internal combustion engines.

Three types of hazardous situations need to be considered when performing hot work:

- (a) the presence of flammable materials in the equipment;
- (b) the presence of combustible materials that burn or give off flammable vapours when heated; and
- (c) the presence of flammable gas in the atmosphere, or gas entering from an adjacent area, such as sewers that have not been properly protected. (Portable detectors for combustible gases can be placed in the area to warn workers of the entry of these gases.)

Cold Work Permit

Cold work permits are used in hazardous maintenance work that does not involve "hot work". Cold work permits are issued when there is no reasonable source of ignition, and when all contact with harmful substances has been eliminated or appropriate precautions taken.

Confined Space Entry Permit

Confined space entry permits are used when entering any confined space such as a tank, vessel, tower, pit or sewer. The permit should be used in conjunction with a "Code of Practice" which describes all important safety aspects of the operation.



Special Permits

Some employers use special permits to cover specific hazards such as:

- extremely hazardous conditions;
- radioactive materials:
- PCBs and other dangerous chemicals;
- excavations; and
- power supplies.

Each type of permit provides a checklist for the person preparing the equipment, informs workers carrying out the work of the hazards present, lists or describes the precautions to be taken, and describes the personal protective equipment to be worn by workers.

General procedure

Safe work permits are usually made out in either duplicate or triplicate. When a duplicate system is used, one copy of the permit is retained by the issuer at the work site and the other is held by the worker/department doing the work. The permit should always be available at the work site. The permit is handed back to the issuer at the end of the shift or when the work is completed.

In a triplicate permit system, the third copy is used by the safety department to audit the work to see if the requirements of the permit are being met.

Example of a safe work permit checklist

A safe work permit is a written record that identifies:

- (1) the date, time of issue, and time of expiry of the permit;
- (2) the location of the work —it must be as specific as possible;
- (3) the department or company doing the work;
- (4) a description of the work to be done;
- (5) any toxic, corrosive, flammable, or other dangerous materials in the immediate work area;
- (6) whether the work area has been inspected and found free of the above materials;
- (7) the need for fire protection;
- (8) the need for isolation electrical and mechanical hazards locked out and tagged, piping blanked off, tagged, disconnected, drained, or vented;
- (9) the need for ventilation air, steam, inert gas purge;
- (10) the need for testing prior to or during the work for:
 - harmful substances;
 - combustible gases;



- oxygen deficiency;
- other hazards e.g. radiation; any specific health hazard is Material Safety Data Sheet information required?;
- (11) the need for specific personal protective equipment to protect the worker from the hazard;
- (12) the need for specific personal protective equipment to protect the worker from the hazard;
- (13) the need for emergency procedures and competent rescue personnel;
- (14) a special instructions and comments section special procedures, special precautions;
- (15) a general instruction-to-receiver section;
- (16) the name and job title of the person who issued the permit and when;
- (17) the name and job title of the person who received the permit and when;
- (18) that the work has been completed and the permit signed by the person returning it; and
- (19) the name of the person signing off the permit and whether or not the work has been completed.

Considerations when using a safe work permit

A safe work permit should only be issued by a competent person who is completely familiar with the work or situation covered by the permit and who has control over changes in that work area e.g. lead operator or supervisor.

The permit issuer must be sure that the work situation identified on the permit is as described. Where possible, the permit issuer should review the work or operation with the worker before work begins. If the permit issuer has not reviewed the site, this should be noted on the permit and the work situation should be discussed with the worker.

Written instructions alone are often insufficient in the effective use of a permit system. Practical training exercises for the people who issue and receive permits should be considered.

The person receiving the permit must completely understand the work situation, the potential hazards, and the precautions required before accepting the permit.

Any special precautions not normally associated with the particular work should be identified to the receiver of the permit, who must fully understand the reasons for these precautions e.g. work to be done in an area where there is a possible exposure to H_2S gas.



The permit issuer must be sure that the worker understands the hazards. If not, the permit issuer needs to review the Material Safety Data Sheet or other information with the worker to ensure that they understand the dangers of the product and the precautions to be taken.

No one should sign a safe work permit unless completely satisfied that the work can be done safely.

All safe work permits must be signed by both the permit receiver and the permit issuer before work is started and after it is completed.

Pitfalls of work permits

Workers and supervisors do not always see the need for a safe work permit system. They have not been trained to recognize the added safeguards that such a program provides.

Factors leading to ineffective permit systems are:

- The type or format of the permit does not cover all the potential hazards.
- The issuing procedure is inadequate.
- The person signing the permit has not inspected the operation to see if the isolation, lock-out, or testing has been done.
- Workers are not following or don't understand the requirements of the permit, especially the expiry time.
- The employer is not enforcing or auditing the work permit system.
- Permits are prepared too far in advance, or after the work has begun.
- A responsible person is not inspecting the operation after the permit has been issued.
- The system is too complex.

Conclusion

All workers using permits must completely understand the reasons for, and the requirements of, the permit before work begins.

A safe work permit is an effective tool to help identify and control hazards, prevent injuries, and avoid costly mistakes.

The following pages provide samples of safe work permits.



SAFE WORK PERMIT FOR HOT WORK NO WORK IS ALLOWED EXCEPT THAT WHICH IS SHOWN ON THE PERMIT

| DATE OF ISSUE LOCATION OF WORK DEPARTMENT DOING WORK DESCRIPTION OF WORK TO BE DO | | | | | |
|---|---------------------------------|-----------------------------------|-------------|----------|-----|
| NAME MATERIALS SHIP | T0.//0 | 000000000 | | | |
| NAME MATERIALS ONLY | TOXIC | CORROSIVE | | | |
| FLAMMABLE | OTHER | | N/A | NO | YES |
| (1) Has an inspection been made o | f the unit/equipment to be v | worked on? | | | |
| (2) Where inspected, was it found to | | erials? | | | |
| (3) Is an adequate supply of fresh a | | | | | |
| (4) Do unit and atmospheric conditi(5) Equipment has been cleaned by | | | | | |
| (5) Equipment has been cleaned by | (Specily) | | | | |
| (6) The necessary equipment has be | een adequately protected b | y (Specify) | | | |
| (7) Have electrical switches been loc | cked out and tagged? | | | | |
| Signature for Process: | Electrical: | | | | |
| Mechanical: | Other: | | | | |
| (8) Have combustible waste materia | le haan ramayad from tha | 27022 | | | |
| (9) Have nearby sewers been prope | | aiea: | | | |
| (10) Is fire protection required? (Spec | | | | | |
| (11) (a) May underground obstruction | ns be encountered? | | | | |
| (b) May underground or overhed (c) Signature of electrical supe | rvisor or designate: | e encountered? | | | |
| (12) Have precautions been taken ag (13) Is permit receiver aware of mater | | pining to this ish? | | | |
| (14) Is there a need to review a speci | | | | | |
| confined space entry, Hydrofluor | | ing assestes, pyrophone materials | ' | | |
| (15) Are gas tests required during the | | | | | |
| (16) Has the confined space or vesse | | ntry and entry signs installed? | | | |
| (17) Is it permissible to use (a) Ele | | | | | |
| (b) Die (18) Is welding permitted? | esel, gasoline & propane dr | iven equipment? | | | |
| | TESTS REQUIRED & RE | SULTS OBTAINED (Check Wher | e Required) | | |
| I examined the above equipment at _ Combustible:% Hydrogen S Gas Tester's Signa | AM/PM & obs Sulphide: ppm Ox | served the reading to be: | | | |
| What additional protective equipment | is required? (Specify) | | | | |
| | is required. (epociny) | | | - | |
| PRECAUT | TONS TO BE FOLLOWED | OTHER THAN THOSE LISTED A | BOVE | | |
| AGREEMENT: I HAVE CHECKED BOWORK AND THE PRECAUTIONS TO | BE FOLLOWED IN COMI | PLETING THE WORK. | TURE AND EX | XTENT OF | THE |
| Permit Issued by: | Job Title: | | | | |
| Received by: | Job litle | : Time: | | | |
| Permit Work Complete: | Job Title: | Time: | | | |
| Sign For Permit Issuer: | Job Title | : Time: | | | |
| Off Work Not Complete: | Job Title | e: Time: | | | |
| All Safe Work Permits must be signed | by both the Darmit Darain | or and | 1 | | |
| Permit Issuer before work is started a | | ei aiiu | Permit No: | | |



| | Persons issui | ng or rece nits and m | iving plar | nt Safe \ realize t | heir respo | its must nsibilities | understand | Work Order N d the procedures se of plant oper | for is | suing a | ınd | |
|-----------------|------------------------------------|--------------------------|------------|------------------------|---|-------------------------|---------------|--|----------------|---------|--------------------|----------|
| Date Iss | ued: | | | Т | ime Issued | d: | | GOOD ON | LY FO | R DAT | E OF IS | SSUE |
| Departm | ent: | | | | | Bui | lding: | | | | | |
| Descript | ion of Work To | Be Done | : | | | | | | | | | |
| Departm | ent or Contrac | ctor Doing | Work: | | | | | | | | | |
| Person i | n Charge of W | ork: | | | | | | | | | | |
| (Note: In | the following, | check Ye | s, No, or | Not Ap | plicable [N | /A]) | | | | YES | NO | N/A |
| 1. Have | e process mate | erials (liqu | id, gas) b | een rer | noved from | n the equ | ipment? | | | | | |
| 2. Has | the equipmen | t been clea | aned by: | (b) (c) | Steaming? Flushing Inert gas Air ventila | with wate purging? | | | | | | |
| | the necessary | | nt been | (a) | | /Blinding | | | | | | |
| adeo | quately protect | ed by: | | (b) (c) | Double E Disconn | | l Bleed | | - | | | |
| | | | | (d) | | and ven | ting? | | ŀ | | | |
| | e all electrical | | | | | | | | | | | |
| | ere an adequa permissible to | | of fresh a | |) Open fla | ame/weld | ling equipn | nent? | - | | | |
| 00 | | | | (b |) Electric | al equipn | nent/tools? | | F | | | |
| | | | | | | e, propa | ne or diese | l driven equipm | ent | | | |
| 7. Can 8 Wha | sparks ignite r | material ai | ound or I | below tr | ns level? | uisher [|)rv chem | □ Co₂ □ H₂O | п | | | |
| o. wiid | t me protectio | 11 13 110003 | sury: | (b) | Firewatch Other (Sp | | ory circin | | | | | |
| | e precautions l | | | | | | | | | | | |
| | atmospheric co es this work inv | | | directio | n permit sa | afe work | near vents | ? | | | | |
| | the confined | | | en prep | ared for sa | fe entry? | | | | | | - |
| 13. Is a | gas test neces | sary? | | | | | | | | | | |
| | | | | | ous 🗆 T | | | Equipment MX | -241 | | | |
| Time | Explo Gas % | O ₂ % | CO ppm | CO ₂ | H ₂ S ppm | NH ₂ ppm | SO₂ Ppm | Other (Spec,) | | | Tester's nature | ; |
| | | ,,, | FF | , , | FF··· | FF | | (0) | | | | |
| | | | | | | | | | | | | |
| 14 Ide | l ntify materials | normally i | n equipm | ent | | | | | | | | |
| (a) | Toxic: | (b |) Flamma | able: | ((| c) Corros | ive | (d) Other (| descril | be): | | |
| | at personal pr | | | is requ | ired? (Spe | ecify) | | | | | | |
| (a) (b) | Type of eye Type of prot | ective clot | hing: | | | | | | | | | |
| | Type of resp | | | | | | | | | | | |
| | Type of ear Other (Spec | | | | | | | | | | | |
| | L INSTRUCTI | | ecify): | | | | | | | | | |
| | | ` ' | , – | | | | | | | | | |
| | | | | | | | | | | | | |
| THE DE | DMIT DECEN | CD ACKA | IOWLED | OFC T | 1 A T 11 F 14/ | 11 1 INIT | DM ALL | PERSONNEL W | OBKI | 10 111 | DED T | |
| | RITY OF THIS | | | | | | | | UKKII | NG UN | DEK II | пЕ |
| Permit is | ssued by: | | | | Job Tit | | | | Γime: | | | |
| | eceived by: | | | | Job Tit | | | | | | | |
| | ompleted: accepted by: | | | | Job Tit | le: .le: | | | Γime: Time: | | | |
| The follo | wing person(s | s) acknowl | edges th | at this jo | b is in pro | gress du | ring shift cl | nange and has o | | d both | the per | m it |
| | nature of the j | | | - | | | wed: | Ch:tt. | | | | |
| | sor Signature: sor Signature: | | | | _ Time: Time: | | | Shift: Shift: | | | | |
| | | | | | | | | | | | | |
| DISPLAY | AT WORKPL | ACE - MA | AINTENA | NCEC | OPY | | | Pern NO | | | | |



| SAFE WORK PERMIT | | | | | |
|--|--|-----------------|-----------|-------|--------------------|
| Date: | , 20 | Time: | | | |
| Description of Work To Be Done: | | | | | |
| | | | | | |
| Location: | Depa | ırtment Doina W | /ork: | | |
| No.of Workers: | Perm | | | | |
| COLD WORK PERMI | T 🗆 | WORK | CLEARANCE | |] |
| Is equipment to be depressu | urized? | | REQUIRED | NO. | DONE (Initials) |
| 2. Is equipment to be isolated a | | rom | | | |
| Are electrical switches to be Should special protective eq | | | | | |
| | | | | | |
| For isolating and testing not done the Permit Issuer see: | e by | | | | |
| REMARKS: Special precautions | s, etc. | | | | |
| | | | | | |
| Permit issued by: | | Department | :: | | |
| (Signatur | re) | | | | |
| | RK TO BE CARRIED OUT U E INDICATED "REQUIRED" | | | | |
| | ESPONSIBILITY OF THE PE | | | | |
| Work completed (Including Clean-up) | Time: | Signat | ure: | | |
| Work Not Completed: | Time: | - | iture: | | |
| RETURN THIS PERM | IIT WHEN WORK IS | | _ | ND OF | SHIFT |



| SAFE WORK PERMIT | | | | | | |
|---|---|---------------------|-----|--------------------|--|--|
| Pate: | 20 Time: | | | | | |
| Description of Work To Be Done: | | | | | | |
| Location: No.of Workers: | | Doing Work:ired By: | | | | |
| | HOT WORK PE | RMIT | | | | |
| 4 . Is equipment to be isolated5. Is equipment to be inspecte hazards? | ly ventilated? r gas to ensure it is gas free? and tagged? d to ensure all parts are free from pote and wind direction to be checked to ons? eck with polyethylene dept.) wer basins? ded? hand? blocked in the "off" position? quipment be used? | ential | NO. | DONE (Initials) | | |
| Permit issued by:(Signatu | | partment: | | | | |
| | RK TO BE CARRIED OUT UNDER T E INDICATED "REQUIRED" ITEMS | | | | | |
| | ESPONSIBILITY OF THE PERMIT IS CK CONDITIONS DURING PROGR | | | | | |
| Work completed (Including Clean-up) | Time: | Signature: | | | | |
| Work Not Completed: | Time: | Signature: | | | | |

SH013 — General Safety Revised May 2007 – Reformatted October 2010



Contact us:

Province-Wide Contact Centre

Web Site

Edmonton 780-415-8690



www.worksafe.alberta.ca



Throughout Alberta 1-866-415-8690 (Toll Free)



Deaf or hearing impaired

- Edmonton 780-427-9999
- Other locations 1-800-232-7215 (Toll Free)

Getting copies of OHS Act, Regulation & Code:

Queen's Printer

Workplace Health and Safety



www.qp.gov.ab.ca



http://employment.alberta.ca/whs-ohs



Edmonton 780-427-4952

Call any Government of Alberta office toll-free Dial 310-0000, then the area code and telephone number you want to reach

© 201--2011, Government of Alberta, Employment and Immigration

This material may be used, reproduced, stored or transmitted for non-commercial purposes. The source of this material must be acknowledged when publishing or issuing it to others. This material is not to be used, reproduced, stored or transmitted for commercial purposes without written permission from the Government of Alberta, Employment and Immigration . This material is to be used for information purposes only no warranty express or implied is given as to the accuracy or the timeliness of the material presented.